

# H2O ( Water ) Handel Drill

## Plumbers and Landscapers



“ No More Shoveling ”



**\*\* Depending Upon the project you can save up to 80% of shovel digging \*\***

**NOTE : Remove the Metal Pipe when using PVC Pipe.  
Insert the 1/2 Inch Coupling when using the 1/2 PVC Pipe.**

**Insert the 1/2 cupling into the 3/4 cupling which exists on the handle drill**



**Use the 3 / 8 Metal Pipe when finding the Drain Pipe  
Able to intstall PVC Pipes under the driveway & sidewalk**

